

「いざ」という時、適確にしかも最大限に機能を発揮!

■特長

- ① 救助袋用に特別製造したテトロン帆布を使用しています。
- ② テトロン帆布を使用していますので、強度、耐候性は抜群です。
- ③ 降下の際、万一裂傷など考慮し底部のすべり面は帆布を二重にしてあります。
- ④ 学校、病院、百貨店等では、理想的な機能を発揮します。
- ⑤ 脱出口には、衝撃防止の保護マットが取付けてありますので非常に安全です。
- ⑥ 軽量で容積が小さいので、取扱いが簡単です。

操作が簡単で、短時間に多くの人を救出できます。

■使用法 Procedure :

- 1** キャビネットを取り除く。
Remove cabinet.



- 2** 誘導ロープ、砂袋を投下する。
Throw down guide rope and sand bag.



- 3** 救助袋を降り入口金具を起す。
Pull rescue chute down and raise entrance metal frame.



- 4** 固定環にフックをかけロープを引っ張る。
Attach hooks on the fixed ring and stretch rope.



- 5** ロープを止める。
Secure rope.



- 6** 降下準備完了。
You are ready to slide down.



- 7** 上部フレームを握り足から入る。
Hold on the top frame and get yourself in feet first.



- 8** 脱出口からすみやかに安全な場所に避難する。
Exit the chute then waste no time to escape to a safety.



Works and Functions Best in Time of Need!

■Features :

- ① Polyester cloth specially designed for fire escape chute
- ② Strong and weather-proof because of the polyester cloth
- ③ The surface down which to slide near the bottom has a double-layered body cloth structure to prevent abrasive injuries.
- ④ Ideal for schools, hospitals and department stores.
- ⑤ The shock-absorber cushion is mounted on the exit to ensure safety.
- ⑥ Easy to handle because it is light and compact.

Easy to Operate and Saves Many Lives Fast.